

CONTROL EC.

Body Controller Left
A.W.I.D

X031 X032 X034 X038A/B X039 X037 X033A/B X035 X036

X031-1 High-Side Drive
CENTER_CONSOLE_POWER_SOCKET
X031-15 Ground
CENTER_CONSOLE_POWER_SOCKET_GND_RETURN

X031-17 High-Side Drive
USB_PORTS

X031-19 LIN
INDUCTIVE_CHARGER_FRONT_LIN

X031-21 High-Side Drive
HAZARD_SWITCH_ECU

X030A-20 High-Side Drive
CENTER_CONSOLE_DOORWELL_LED

X039-16 High-Side Drive
CENTER_CONSOLE_SLIDING_TRAY_LED

X030A-21 High-Side Drive
CENTER_CONSOLE_BIN_REAR_LED

X030A-8 High-Side Drive
CENTER_CONSOLE_BIN_FRONT_LED

X031-12 High-Side Drive
CENTER_CONSOLE_BIN_FRONT_OPEN_SWITCH

X030A-12 High-Side Drive
CENTER_CONSOLE_BIN_FRONT_OPEN_SWITCH

X030A-20 High-Side Drive
CENTER_CONSOLE_CUPHOLDER_SWITCH

12V Power Socket
C X1130

USB Ports Front
C X1131 X881

USB Ports Rear
C X1132

Inductive Charger Front
C X1133

Hazard + PRND Switch
C X1138

Center Console Center Footwell
C X1124

Center Console Switch - Sliding Tray
C X1129

Center Console Switch - Rear Bin
C X1128

Center Console Light Pipe FL
C X1122

Center Console Light Pipe FR
C X1123

Center Console Switch - Front Bin
C X1127

Center Console Switch - Half Front Bin
C X1115

Center Console Switch - Cupholder
C X1116

TRAY

Center Console Sliding Tray LED
C X1125

Center Console Light Pipe Rear
C X1120

FRONT WELL LEDS.

CONTROL 982

039

CONTROL 983

030

CONTROL x2
PURE LOGIC
SOFTWARE

982

032

982

983

038

TESLA

FOR INFORMATION PURPOSES ONLY. THIS DOCUMENT IS NOT TO BE USED, REPRODUCED, OR OTHERWISE IN ANY MANNER OR FOR ANY PURPOSE WITHOUT THE WRITTEN PERMISSION OF TESLA. ANY VIOLATION OF THESE TERMS WILL BE PROSECUTED TO THE FULL EXTENT OF THE LAW.		
DRAWN	CHECKED	APPROVED
MATERIAL AS SPECIFIED	FINISHING AS SPECIFIED	SCALE NONE
PART NAME Center Console		
PART NUMBER	REV	SHEET
	1	15 of 61
		A0