

TPMS Sensor - ID Learn Procedure - Continental

FRT No: 34041100

Setup

1. Press the Power button and watch the display. When the display shows "ATEQ VT30", note the version number:
 - If the version is EA1-07, refer to TN-14-92-005, "ATEQ TPMS Tool Firmware Update" to update the tool's firmware.
 - If the version is higher than EA1-07, continue this procedure.
2. In the Main Menu, use the up and down arrows to select **Vehicle Selection**, then press the Enter (↵) button.
3. Use the up and down arrows to select **Tesla**, then press the Enter button.
4. Use the up and down arrow to select **Left Front**.
5. Hold the ATEQ tool near the valve stem on the left front tire, then press and hold the Read button until the sensor is read.
6. Repeat steps 4 and 5 for the 3 remaining tires.
7. Connect a Laptop with Toolbox 2.0 to the vehicle.
8. In the top menu, select **Tires and Suspension**, then select the **TPMS Setup** tab. Press the Start/Play button and follow the onscreen instructions.